

Setup and Connections:

*******DO NOT TURN ON
COMPUTER UNTIL SETUP IS
COMPLETE!*******

**Place the units on a flat, clean
dry surface.**

1. If you plan on using the floppy disk drive, connect the wire connection to the floppy drive and to the back of the computer.

Floppy disk connected to the laptop.



Power cord plugged into the back left side of the laptop and into the surge protector.

2. Plug the **power cord** into the power supply and the laptop. The power outlet is located on the **back left side** of the laptop. You can now plug the power cord into the surge protector.



DO NOT turn the computer on yet.

3. Connect the **External Mouse** to the mouse/keyboard port located on the back of the computer. Have the **arrow pointing up** and be careful not to bend the pins in the mouse connection. It should slide in easily.

External mouse port.



External mouse plugged into the back left side of the laptop.



4. **Plug the Cat 5 Cord** into a live port in your classroom.

Plug the other side of the Cat 5 cord into the wireless access point.

On the cat 5 cable, push the head in until you hear a click. To remove the cord, push the lever in towards the cord then gently pull the cord out.

Cat 5 wire plugged into access point.



Plug the power adapter into the access point and into the power strip.

Ethernet Wall Jack



Once the access point is connected and powered, check the lights on the front.

Connected access point.



6. Insert the wireless card face-up into the card port on the left side of the laptop. *Be sure that the card is inserted face-up, and that it is fully seated in the slot.*

Once the laptop is powered, the green lights on the card should be active.

Active wireless card



Expansion slot for wireless card.



Wireless card inserted in slot.



7. **Turn on** all the laptops

Note: DO NOT force a laptop open. When opening a laptop, look for a release latch. The latch is located on the front of the laptop.

8. You are now ready to use the networked S.U.I.T.cases For Learning set.

Remember they are checked out for a two-week period.

9. **Troubleshooting Tips:** If the Network doesn't work, shut down all of the computers and unplug the wireless access point. The reconnect and restart the access point and then the computers. Refer to the networking guide on the laminated card in the set for additional networking issues as well as the online handout titled Networking.

If trouble still persists,
email Tech Help at
suitcase@lpsonline.com

*******These computers are not setup to print. Printing can be done from your computer in your classroom. Software may not be installed on these computers. The software we are licensed for is already installed on the laptops; therefore, we are legal only for what is currently on the laptops.*******